

# 25 Ton Ram Operating Instructions

Section 9

**Parts List** 

### **Dixon**

800 High Street • Chestertown, MD 21620 ph: 877•963•4966 fax: 800•283•4966 dixonvalve.com

**25 TONRAM** 

Mulcoram includes 115V pump, 10,000 PSI hose, gauge

### **External Swage Attachments**

Please note that on some sizes, more than two attachments may be necessary. Read carefully through all descriptions to determine which attachments are needed for your applications. Please consult Dixon® if you need more information.

25PUSH400 4" pusher for external swage (pusher hat)

(Needed for all sizes)

25PUSH3003" pusher for external swaging25PUSH2502½" pusher for external swaging

**25PUSH200** 2" pusher for external swaging

25PUSH150 1½" pusher for external swaging

25PUSH125 11/4" pusher for external swaging

DH9-004-1 Die holder needed for 4" only (must use with DH9-004)

**DH9-004** Die holder needed for all sizes

DH6-003 Die holder needed for 1-1/4" to 3"

RST300SPACE 3" spacer ring for NOS ferrules (must use with 25PUSH300E)

RST200SPACE 2" spacer ring for NOS ferrules (must use with D011-018)

RST150SPACE 1½" spacer ring for NOS ferrules (must use with RE150PUSH)

Swage dies not included

Section 10

### Equipment to Swage 11/4" to 4" ID Hose (cont.)

**RN150NOPUSH** 1½" pusher for notched turned back nipple

RN200NOPUSH 2" pusher for notched turned back nipple

**RN300NOPUSH** 3" pusher for notched turned back nipple

**RN400NOPUSH** 4" pusher for notched turned back nipple

M011-331 Pusher for female Holedall (TF16WF1-80)

M011-332 Pusher for female Holedall (TF16WF3-80)

M011-333 Pusher for female Holedall (TF16WF3-80)

**25PUSH125-MOD** Pusher for 1½" female Holedall

**25PUSH200-MOD** Pusher for 2" female Holedall

# **Unirange External Swage**

### Equipment to Install 1/4" to 1" Unirange Couplings

DH9-004	Die holder needed for all Sizes

**DH6-003** Die holder for all Sizes 3" and below

DH3-001 Die holder needed for all Sizes 1" and below
25PUSH100 Pusher adapter (needed for all sizes below)

M011-327 Pusher for 16P1

M011-328 Pusher for 16P2, R16P1620

M011-329 Pusher for 16P3

M011-330 Pusher for 16P4, R16P1770

Pusher for 12P1 M011-320 M011-321 Pusher for 12P2 M011-322 Pusher for 12P3 M011-313 Pusher for 8P1 M011-314 Pusher for 8P2 M011-315 Pusher for 8P3 M011-310 Pusher for 6P1 M011-311 Pusher for 6P2 M011-312 Pusher for 6P3 M011-306 Pusher for 4P1 Pusher for 4P2 M011-307 Pusher for 4P3 M011-308

**AKPUSH** Pusher for Air King® ½" - 1"

Swage dies not included

### Equipment to Swage 1" through 4" Cam & Groove

**DH9-004-1** Die holder needed for 4" only (must be used with **DH9-004**)

DH9-004
 Die holder needed for all sizes
 DH6-003
 Die holder needed for 3" and below
 DH3-001
 Die holder needed for 1" and below

 25PUSH400C
 Pusher for 4" C

 25PUSH400E
 Pusher for 4" E

 25PUSH300E
 Pusher for 3" E

**D011-018** Pusher for 2" C, 2" E and 3" C

 **RC150PUSH** Pusher for 1½" C (two parts)

RE150PUSH Pusher for 1½" E

RC100PUSH Pusher for 1" C

RE100PUSH Pusher for 1" E

150CGSPACE \* Spacer rings for 1½" C
100CGSPACE \* Spacer rings for 1" C

Swage dies not included

<sup>\*</sup> Future designs may not require spacer rings. Contact Dixon® for more information.

### Equipment to Internally Expand Steel IX

25IXATTACH Internal expanding attachment for 25 Ton Ram includes 4" internal expanding adapter

(needed for all sizes)

DH9-004 Die holder/ adapter for 25IXATTACH (needed for all sizes)

**25RODLARGE** IX rod for 2" - 4" hose

25RDLG-A Large rod for only 25TONRAM 25RDLG-B Nut only for 15 & 25 TON RAMS

25RODSMALL IX rod for 1" to 1½" hose

25RDSML-ASmall pull rod25RDSML-BSmall pull rod adapter25RDSML-CNut for small rod

**M011-385** 4" IX adapter (IXM64 only)

**25ADAPT300** 3" IX adapter **25ADAPT250** 2½" IX adapter

**M011-384** 2½" IXM40 adapter (must be used with **25ADAPT250**)

 25ADAPT200
 2" IX adapter

 25ADAPT150
 1½" IX adapter

 25ADAPT125
 1¼" IX adapter

 25ADAPT100
 1" IX adapter

IXPLUG300

4" IX plug for steel & Holedall Petroleum fittings
3" IX plug for steel & Holedall Petroleum fittings
IXPLUG250

2½" IX plug for steel & Holedall Petroleum fittings
IXPLUG200

2" IX plug for steel & Holedall Petroleum fittings
IXPLUG150

1½" plug for steel & Holedall Petroleum fittings
IXPLUG125

1¼" IX plug for steel & Holedall Petroleum fittings
IXPLUG100

1" IX plug for steel & Holedall Petroleum fittings

### Equipment to Internally Expand Flow Chief Food Grade Fittings

25IXATTACH Internal expanding attachment for 25 Ton Ram

includes 4" internal expanding adapter for male NPT

(needed for all sizes)

DH9-004 Die holder (needed for all sizes)

**25RODLARGE** IX rod for 2" - 4" hose

25RDLG-A Large rod for only 25TONRAM
25RDLG-B Nut only for 15 & 25 TON RAMS

**25RODSMALL** IX rod for 1" to 1½" hose

25RDSML-A Small pull rod

25RDSML-B Small pull rod adapter 25RDSML-C Nut for small rod

25ADAPT3003" IX adapter for male NPT25ADAPT2502 ½" IX adapter for male NPT25ADAPT2002" IX adapter for male NPT25ADAPT1501½" IX adapter for male NPT

PFADAPT300 4" sanitary end adapter (Tri Clover style)
PFADAPT300 3" sanitary end adapter (Tri Clover style)
PFADAPT250 2½" sanitary end adapter (Tri Clover style)
PFADAPT200 2" sanitary end adapter (Tri Clover style)
PFADAPT150 1½" sanitary end adapter (Tri Clover style)

**PFADAPT150-3A** 1½" sanitary end adapter for 3A (Tri Clover style)

# Equipment to Internally Expand Flow Chief Food Grade Fittings (cont.)

PFACNTA400 PFACNTA300 PFACNTA250	4" bevel seat Acme nut adapter (must buy PFADAPT400 to use this part) 3" bevel seat Acme nut adapter (must buy PFADAPT300 to use this part) 2½" bevel seat Acme nut adapter (must buy PFADAPT250 to use this part)
PFACNTA200	2" bevel seat Acme nut adapter (must buy PFADAPT200 to use this part)
PFACNTA150	1½" bevel seat Acme nut adapter (must buy PFADAPT150 to use this part)
IXFDPLG400	4" food plug (for stainless steel fittings only)
IXFDPLG300	3" food plug (for stainless steel fittings only)
IXFDPLG250	2½" food plug (for stainless steel fittings only)
IXFDPLG200	2" food plug (for stainless steel fittings only)
IXFDPLG150	1½" food plug (for stainless steel fittings only)
IXFDPLG287	3" 3A food plug (for stainless steel fittings only)
IXFDPLG187	2" 3A food plug (for stainless steel fittings only)
IXFDPLG137	1½" 3A food plug (for stainless steel fittings only)

### Equipment to Internally Expand Holedall Petroleum Fittings

**25IXATTACH** Internal expanding attachment for 25 Ton Ram includes 4" internal expanding adapter for

male NPT (needed for all sizes)

DH9-004 Die holder/adapter for 25IXATTACH (needed for all sizes)

**25ROSTPA** Adapter plate to hold thrust plates

**25ROSTROD** Pull rod for 5%", 3/4" and 1" - consists of the following:

25ROSTROD-A Small Holedall Petroleum pull rod

25DSML-B Small pull rod adapter 25RDSML-C Nut for small rod

**25RODLARGE** Pull rod for 2" through 4" - Consists of the following:

25RDLG-A Large rod for only 25TONRAM 25RDLG-B Nut only for 15 & 25 TON RAMS

**25RODSMALL** Pull rod for 1" to 1½" - consists of the following:

25RDSML-A Small pull rod
25RDSML-B Small pull rod adapter
25RDSML-C Nut for small rod

IXPLUG400 4" IX plug for steel & Holedall Petroleum fittings IXPLUG300 3" IX plug for steel & Holedall Petroleum fittings IXPLUG250 21/2" IX plug for steel & Holedall Petroleum fittings IXPLUG200 2" IX plug for steel & Holedall Petroleum fittings IXPLUG150 11/2" IX plug for steel & Holedall Petroleum fittings IXPLUG138 1%" IX plug for steel & Holedall Petroleum fittings IXPLUG125 11/4" IX plug for steel & Holedall Petroleum fittings IXPLUG100 1" IX plug for steel & Holedall Petroleum fittings

# Equipment to Internally Expand Holedall Petroleum Fittings (cont.)


25000HTL03	1" IX plug (must use <b>25ROSTRO</b> D)
25000HTL02	3/4" IX plug (must use 25ROSTROD)
25000HTL01	%" IX plug (must use <b>25ROSTRO</b> D)
25000HTL26	Thrust plate for 3" aluminum H-520 style fittings
25000HTL25	Thrust plate for 21/2" aluminum H-520 style fittings
25000HTL24	Thrust plate for 2" aluminum H-520 style fittings
25000HTL23	Thrust plate for 4" H-520 style fittings
25000HTL22	Thrust plate for 3" H-520 style fittings
25000HTL21	Thrust plate for 21/2" H-520 style fittings
25000HTL20	Thrust plate for 2" H-520 style fittings
25000HTL19	Thrust plate for 1%" & 11/2" H-520 style fittings
H5211NSTADT	Adapter for NST female 1" H-520 style fittings
H5231NSTADT	Adapter for NST female 11/2" H-520 series couplings
25000HTL18	Thrust plate for 11/4" H-520 style fittings
25000HTL17	Thrust plate for 1" H-520 style fittings
25000HTL16	Thrust plate for 1" x 1½" H570 style fittings Thrust plate for 1" x 1 9/16" H-570 style fittings
25000HTL15	Thrust plate for 1" x 1-25/64" H-570 style fittings Thrust plate for 1" x 1-29/64" H-570 style fittings
25000HTL14	Thrust plate for 3/4" H-520 style fittings
25000HTL13	Thrust plate for 3/4" x 1-7/32" H-570/H580 fittings
25000HTL12	Thrust plate for $\frac{3}{4}$ " x 1-9/64" H-570/H580 fittings Thrust plate for $\frac{3}{4}$ " x 1-11/64" H-570/H580 fittings Thrust plate for $\frac{3}{4}$ " x 1-13/64" H-570/H580 fittings

Thrust plate for %" H-570 fittings


25000HTL11

<sup>\*</sup> Consult Dixon® for the necessary attachments to use the Scovill style plugs (11/4" - 4")


### 25 Ton Ram Parts - External Swaging




Die Holder




**Pusher Plate** 




Pusher Hat (4")



**Pusher Adapter** 




**Unirange Pusher** 




**RSTXXX Spacer** 




Cam & Groove Space Ring



1½" Cam & Groove Pusher




3" & 4" Cam & Groove Pusher



2" Type C & E Cam & Groove Pusher; 3" Type C Cam & Groove Pusher

These drawings represent the overall shape of the parts only. Please consult the complete Ram Attachments listing for specific descriptions regarding size, usage, etc.

### 25 Ton Ram Parts - Internal Expansion



These drawings represent the overall shape of the parts only. Please consult the complete Ram Attachments listing for specific descriptions regarding size, usage, etc.

# **PUMP INSTALLATION**

